

## Palatine Models W&L Wagon Brake Gear

This etch contains enough components to produce brake gear for 12 wagons. There are levers for both wagons and vans and it is intended that 2 levers are soldered together to provide the required thickness. The photos below show the prototype and can be used to produce the necessary bends.



The lever guards are best fitted to the wagon body using short pieces of wire which can be soldered into holes which can be drilled in the half etch dimples on the back of the guard. For the open wagon cut of the top part of the lever guard etch, for the Private Owner wagon cut of the side parts of the lever guard etch.

The brake guard has been deliberately left long so that you can produce any necessary bends that you require to attach it to the wagon floor.

